



DAMAGE DOMINO Target System*


After
4000
arrows




6000




10000




12000




16000




18000




22000




24000




28000




30000



34000



36000



A minimum of 54000 arrows
can be shot before you have
to replace any parts.
(6000 shot pr. Centre)

54000
shot

ddts-4-1-54000

* PATENT PENDING

DAMAGE of Scandinavia, Industrivej 13, 6310 Broager, Denmark
Tel.: +45 74 44 26 36, fax: +45 74 44 26 24, E-mail: danage@danage.dk, homepage: www.danage.dk